

# Rotax Engine Tips

<b>Cat.</b>	<b>Float Height</b>	<b>Air Screw</b>	<b>Main Jet Range</b>	<b>Needle Position</b>	<b>Main Jet Recom.</b>
<b>MY20 Mini</b>	<b>3 mm</b>	<b>2.0</b>	<b>105-115</b>	<b>p4</b>	<b>112</b>
<b>MY20 Micro</b>	<b>3 mm</b>	<b>2.0</b>	<b>105-115</b>	<b>p4</b>	<b>110</b>

- **Ensure you charge your battery, this is important for performance**
- **Generally if engine performance is 'flat' you are too lean on jetting**
- **Recommended plug Gap < 1.15 mm MY20 Micro & Mini**
- **MY20 Micro 85 celsius : 185 Fahrenheit**
- **MY20 Mini 65 celsius : 149 Fahrenheit**



**#RACEROTAX**